

METLAM AUSTRALIA STAINLESS STEEL PRODUCT CLEANING AND MAINTENANCE GUIDE

- * Before commencing any cleaning regime, remember to disconnect any electrical cables.
- * Metlam stainless steel products look best when cleaned regularly with a clean damp cloth.
- * Drying afterwards makes sure streaky marks aren't left behind.
- * Routine cleaning prevents any stubborn stains from building up and ensures best results on finish.

WHAT TO USE

For day to day cleaning use water, mild detergent and a clean cloth.

Do not use bleach or commercial chemical cleaning agents as this will break down the coating on the stainless steel.

After cleaning, wipe the surface dry with a soft absorbent cloth.

AVOID SCRATCHES

Stainless Steel can be scratched by careless handling or aggressive scrubbing.

Avoid dragging rough items across the surface and be aware that grit, trapped under other materials, can actually cause surface scratches.

CHEMICAL REACTION

If left in contact with salts or acids for extended periods, Metlam Australia Stainless Steel products may be compromised. Applying regular hygiene measures, like a maintenance/cleaning schedule, will minimise any potential problems.

Using incorrect cleaning products can damage your Metlam stainless steel product and void the warranty.

AVOID:

- * Rubbing with steel wool (wire wool) or scraping with steel tools
- * Using scourers and cleaning cloths that have been used on ordinary steel
- * Rubbing plastic scourers across the grain of brushed surfaces
- * Using concentrated bleach or hydrochloric acid-based cleaning products
- * Contact with products containing chlorine bleach, hydrochloric or muriatic acid

For more information on cleaning stainless steel, visit the <u>Australian Stainless Steel Development</u> Association.

The technical recommendations contained in this document are necessarily of a general nature and should not be relied on for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any stainless steel product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.

The photographs and line drawings of the products presented above are representational only.

Metlam Australia Pty Ltd reserves the right to, and from time to time, make changes and improvements in design and dimensions

Metlam Australia Pty Ltd T: +61 3 5420 8800 F: +61 3 5420 8899 E: sales@metlam.com.au www.metlam.com.au