

## **CORRECT CHOICE OF CONSUMABLES FOR METLAM AUSTRALIA DISPENSERS (SOAP, TOILET ROLL & PAPER TOWEL)**

### **METLAM AUSTRALIA DISPENSER GUIDELINES**

As Metlam Australia does not sell consumable products, the products listed below reflect the most popular range of consumables in the market. There are also many product equivalents that can be successfully utilised in Metlam dispensers, use below as a guide to the Metlam suitability requirements. Please note, Metlam recommends that any consumable is trialed prior to being purchased to ensure suitability as manufacturers of products may change dimensions and ingredients without notification to Metlam.

### **GUIDING PRINCIPLE**

The key to finding the correct products to put in your Metlam Australia dispenser is knowing the width and depth of your product and maximizing the internal space available. **Note:** If the paper is too narrow it may fall out of the dispenser in clumps and if the soap is too thick and thin, it may block the pump and leak through the valve.

### **WHAT TYPE OF SOAP DO I USE IN MY METLAM SOAP DISPENSER?**

Metlam recommends the use of commercially available liquid soap. The soap used in our Stainless Steel Dispensers should preferably:

- Be coconut and vegetable oil based;
- Have a neutral pH (6.5 - 9.0) and;
- Be free from any alcohol, solvents and abrasive particles. The use of these can cause irreparable damage to your dispenser including staining, corrosion, degradation of the plastic and rubber inside the valve and can void your warranty.

The soap used should be viscous and have a thickness between 1,000 and 5,000 CPS (centipoises), bearing in mind that soap viscosity changes dependent on the ambient temperature. A good rule of thumb to follow is that the soap should flow freely at room temperature. Remember, thinner soaps are more likely to leak from your valve and thicker soaps lower the dosing volume.

For Foam Soap Dispensers the Viscosity Range for commercially suitable foam soap should be between 250-2,500 CPS (centipoises).

### **CONSUMABLE SUPPLIERS**

Consumable products for Metlam Dispensers can be purchased from all consumable suppliers, the most commonly known of these include:

- [Caprice Paper](#)
- [John S Hayes](#)
- [Melbourne Cleaning Supplies](#)
- [Officeworks](#)
- [Office Choice](#)

For further Consumable advice contact your local Metlam Australia Business Development Manager, Regional Sales Manager and contact our Head Office on 1300 METLAM.

# Information Sheet



Metlam Dispenser Code	Dispenser Type	Overall Dimensions (Storage Compartment)	Suitable Products Available	
<b>Liquid Soap</b>				
ML606 and ML615B	Commercial Grade Liquid Soap	400mL	<b>Hexa</b> 070101 and 070104 <b>Northfork</b> 635010700, 635010800 and 635020700 <b>Regal</b> RSOAP5L and RSOAP5WL	
ML616_4 and ML616_6		475mL		
ML635		475mL		
ML655 and ML663		600mL		
ML610		700mL		
ML_950SD_SS		<b>Viscosity Range: 1,000 - 5,000cps (centipoises)</b>		900mL
ML628_4 and ML628_6				950mL
ML_950DA_WHT				950mL
ML600, ML602, ML603, ML605, ML640AS, ML641AS and DESIGNER_ML605AS		<b>pH Range: 6.5-9.0</b>		1.2L
<b>Foam Soap</b>				
ML681F	Foam Soap	750mL	<b>Supreme Clean</b> 072301	
ML681SSF		1000mL		
ML_MSD_FOAMDISP_SS		800mL		
<b>Paper Towel</b>				
ML_ECO_73N1REC and ML_ECO_73N1SM	Interfold or Interleaved Paper Towel	257mmW x 106mmD	<b>Enviro~Saver</b> ES150 <b>Tork</b> 0170370, 2310769 and 148430 <b>Kleenex</b> 4456 <b>Scott</b> 13207 and 4457 <b>Caprice</b> 4000CU and 1620CW	
ML_ECLIPSE_3N1REC_D				
ML707		265mm W x 80mmD		
ML710				
ML725				
ML726		282mmW x 104mmD		
ML705, ML706 and ML727	Slimline Folded Towel	265mmW x 70mmD	<b>Scott</b> 60218 and KI5855 <b>Enviro~Saver</b> ES162 <b>Tork</b> 0148430 and 0184987 <b>Kleenex</b> KI44400KT and KI44400	
ML4093SS, ML4093W, ML4093SS_LOCKABLE and ML4093W_LOCKABLE	Paper Towel Roll	220mmW x 180mmD	<b>TruSoft</b> TRT100 and TRT80 <b>Tork</b> 2187951, SC56081 and SC290016	
<b>Toilet Roll &amp; Paper</b>				
ML113, ML513, ML225, ML256, ML260, ML261,	Standard Toilet Roll	Up to 400 Sheets per roll	<b>Scott</b> KI57410 <b>Tork</b>	

# Information Sheet



ML262, ML263, ML267, ML800, ML801, ML820, ML820A, ML825, ML832, ML833, ML835, ML836, ML837, ML838, ML3355B, DESIGNER_2707, ML949_375, ML5856, ML6000, ML6002, ML6004, ML6048, ML6049, ML6050, ML6224, ML6225, ML6226, ML4135, ML4135_2, 700_SS_TRH, 700_SS_2TRH, MLR50TPH and MLR50NCAL_TPH			SC23400, SC2170329 and 0127530 <b>Kleenex</b> KI4737 ad KI4735 <b>Regal</b> B2400V
ML4094SS & ML4094W	Interfold Toilet Paper	142mmW x 242mmH x 43mmD	<b>Kimberley Clark</b> KI4301 <b>Regal</b> IT4001 and IT2502
ML840, ML841, ML841DBL, ML842, ML843 and ML862	Jumbo Toilet Roll	Jumbo Rolls up to 300mL	<b>Enviro~Saver</b> ESJ300 <b>TruSoft</b> JR3002R <b>Stella</b> ST3000
<b>Facial Tissues</b>			
ML275_BSM	Facial Tissue	267mmW x 64mmD	<b>Regal</b> FT1002 <b>Tork</b> 2311408 <b>Kleenex</b> KI04720
<b>Air Freshener</b>			
ML230AD	Auto Air Freshener	Replaceable Commercial Aerosol	<b>Air Wick</b> 8141111, 8141113 and 8141115

The technical recommendations contained in this document are necessarily of a general nature and should not be relied upon for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, and in accordance with ASSDA recommendations, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.