

## METLAM AUSTRALIA STAINLESS STEEL & ABS SOAP DISPENSER CLEANING AND MAINTENANCE GUIDE

Maintaining a clean and functional Soap Dispenser is just a matter of a few simple steps. Expensive cleaning agents or special equipment is not required. We suggest an ordinary household cleaner is usually all that is required should the following guidelines be adhered to.

### KEEPING THE EXTERNAL UNIT CLEAN

- Metlam Soap Dispensers look and operate best if they are cleaned regularly with plenty of water.
- Drying afterwards makes sure streaky marks aren't left behind.
- Wiping with a damp cloth is basically ineffective, as it can smear dirt without removing it.
- Routine cleaning prevents any stubborn stains building up.

### WHAT TO USE

For day to day cleaning, plenty of water, some mild detergent and a cloth or soft brush will work best. You can use a 1% ammonia solution **but don't use bleach**, it's just too easy to make the solution too strong making it difficult to properly rinse it off the surface afterwards. After washing, thoroughly rinse with clean water and wipe the surface dry with a soft absorbent cloth. On brushed Zinc Alloy Diecast, follow the direction of the grain for best results. An excellent cloth to use is **3M's Scotch-Brite High Performance Cleaning Cloth**.

### AVOID SCRATCHES

Note that Satin Stainless Steel or ABS can be scratched by careless handling or aggressive scrubbing.

Avoid dragging rough items across the surface and be aware that grit trapped under other materials on the unit can actually cause surface scratches.

### HANDLING TOUGH MARKS & STAINS

For fingerprint, oil and grease marks a mild detergent or dishwashing detergent works best. If this type of product doesn't shift unsightly finger marks, a quality glass cleaner on a soft cloth should eliminate these. Use of a small amount of alcohol, methylated spirits, acetone or mineral turpentine will also remove these types of marks. Thoroughly rinse with clean water and dry immediately after. Longer protection for high volume usage items can be achieved by lightly rubbing with olive oil or baby oil followed by a polish and shine using a soft cloth.

### CLEANING THE INTERNAL COMPARTMENT OF YOUR METLAM AUSTRALIA SOAP DISPENSER:

#### **Stainless Steel Soap Dispensers:**

To ensure best performance of your Metlam Soap Dispenser, it is recommended that the unit be periodically (every 12-16 weeks) removed from the wall and flushed out using hot water.

The unit can be removed from the wall by releasing the grub screw located inside refill lid and lifted up off the wall bracket.

The valves also require a similar maintenance schedule, by pumping hot water through these to clear any soap build up trapped inside.

In some cases where a Soap Dispenser has lay dormant and unused for some time, the valves can clog. In this scenario we recommend the valves be unscrewed from the face of the unit (be sure to empty any remaining soap first) and soaked in hot water for at least 30 minutes, pumping the valve 15-30 times while submerged to clear any soap residue from inside.

### **ABS Soap Dispensers:**

First remove soap dispenser from wall bracket where possible and then remove the tank from the unit (if there is a tank insert). Empty all soap from tank and flush tank with warm water to remove any dried or thickened soap residue. Once clean, reinstall tank into unit.

### **Note for both Stainless Steel and ABS Saper Dispenser Units:**

*After you refill soap tank on manual push button Soap Dispensers you MUST prime valve in order to start soap flow. Place finger on drip spout and push valve in. Remove finger and let valve come out. Repeat this until valve startes to dispense liquid soap in hand.*

### **NEVER USE:**

- Steel wool (wire wool) or scraping with steel tools
- Stainless Steel scouring pads including pre-used scourers as these will scratch the finish of both your Stainless Steel or ABS Soap Dispenser
- Rubbing plastic scourers across the grain of brushed surfaces
- Using concentrated bleach or hydrochloric acid-based cleaning products
- Contact with product containing chlorine bleach, hydrochloric or muriatic acid

The technical recommendations contained in this document are necessarily of a general nature and should not be relied upon for specific applications without first securing competent advice. Whilst Metlam Australia Pty Ltd has taken all reasonable steps to ensure the information contained herein is accurate and current, and in accordance with ASSDA recommendations, it does not warrant the accuracy or completeness of the information and does not accept liability for errors or omissions. Any Commercial product should only be installed by a competent tradesperson and serviced/maintained by knowledgeable janitorial staff or competent people. Metlam Australia accepts no responsibility for any damage to product, walls or fixtures due to incorrect installation or maintenance of any of their products.